

Guidelines
On
Special MR Ring and Cover Requirements

I. Cam Locks

Cam Locks are required on covers in the following locations:

- A. When bolt-down manhole rings are required.
- B. When the cover is in a flood plain, creek channel or any other area subject to flooding.
- C. On all field inlet tops in residential areas.
- D. On all curb inlet tops.

II. Vented Covers

- A. Vented covers will not be used in new construction.
- B. During repair work on sanitary and combined sewers, any vented cover will be replaced with a nonvented cover.
- C. Vented covers may be salvaged for repair work on storm sewers.

III. Bolt-Down MH Rings

Manhole rings are only required to be bolted down on "pressure" sewers.

Entry No. 950769
Date: Nov. 29, 1995

George E. Wolf, Jr., P.E.
Director of Public Works

Gurnie C. Gunter, P.E.
Director of Water Services